

66†† —
SPACER FOR
1/2" FLOORING

IP1084-1REV.G 6/01
USED WITH PARTS LIST IP1084-2 AND 103697 OPERATION AND MAINTENANCE MANUAL